

# Vacuum Air Sampling Box

CEL Scientific Corporation  
Your Reliable Supplier of Environmental Sampling Products

## Features

- Fill bag without sample passing through pump
- Automatically stop to avoid burst of bag when bag is full
- Purge function to flush bag
- Clear-view lid
- Over 100 samples collecting with a full charge
- Accommodates 0.5L ~ 2L sampling bags
- Storage room at the bottom
- Durable and light-weighted case



## Operating Instruction



1. Turn on the power
2. Open the sampling box
3. Place a Tedlar bag inside the sampling box by attaching its eyelet to the fixing pole
4. Connect the flexible tubing inside the box to the stem of the valve of the Tedlar bag
5. Open the valve and close the sampling box tightly
6. Press “SAMPLE” button on the control panel to start sampling
7. Air sample begins to flow inside the bag and sampling box automatically stops when the bag is full
8. Open the lid in 5~10 seconds, close the valve of the Tedlar bag, and remove the bag from the tubing
9. If a bag needs to be flushed, press “PURGE” button. When the bag is empty, press “STOP”

Please call us at 1-800-214-0845  
or visit us online at [www.celscientific.com](http://www.celscientific.com)  
for more information and to place an order.